# Gauges and meters



The units used on the speedometer and the tachometer gauge display may differ depending on the model/type.

The following gauges, meters and display illuminate when the "ENGINE START STOP" switch is in IGNITION ON mode.

- Speedometer Displays the vehicle speed.
- ✓ Multi-information display→P. 139
- Tachometer
  Displays the engine speed in revolutions per minute.
- ✓ Tacho indicator
  When the set engine speed is reached, this ring-shaped indicators comes on in yellow. The indicator comes on in red when the engine speed reaches a dangerous range.
- **5** Engine coolant temperature gauge Displays the engine coolant temperature.

6 Odometer and trip meter

Odometer: Displays the total distance the vehicle has been driven.

Trip meter: Displays the distance the vehicle has been driven since

the meter was last reset. Trip meters "A" and "B" can be used to record and display different distances indepen-

dently.

Speed indicator

When the set speed is reached while driving, this ring-shaped indicator comes on in yellow. The indicator comes on in red when the vehicle speed reaches the dangerous range.

8 Fuel gauge

Displays the quantity of fuel remaining in the tank.

Odometer/trip meter and trip meter reset button
Switches between odometer and trip meter displays. Pushing and holding
the button will reset the trip meter when the trip meter is being displayed.

### Instrument panel light control

The brightness of the instrument panel lights can be adjusted.



- 1 Darker
- 2 Brighter

# Speed and tacho indicators

### n Turning the indicator on/off




Bring up the satellite switch mode on the multi-information display.

Press <, > or the "ON/OFF" button.



Select the item whose setting is to be changed.

Press < or > to display the item whose setting is to be changed.




Change the settings.

Press "ON/OFF" button to change the settings (e.g. on/off).


### n Changing the indicator setting

The satellite switch can be used to change the set speed at which the yellow speed or tacho indicator ring comes on.

The setting can be made only when the "ENGINE START STOP" switch is in IGNITION ON mode and the vehicle is stopped.



Push < or > to select the speed or tacho indicator set mode. (11) Turn the speed or tacho indicator to "OFF" and then "ON" by pushing the "ON/OFF" button. (21)



After one second, the mode enters the indicator setting mode.

The speedometer or tachometer needle moves to the previously set speed.



Push < or > within 6 seconds of the speedometer or tachometer needle moving to change the setting of the desired speed, then turn the indicator mode to "ON" by pushing the "ON/OFF" button.

Pushing and holding the switch changes values at a faster rate.

If the satellite switch is not operated for some time, the multi-information display returns to its previously displayed content.



The yellow indicator is displayed to indicate that the desired speed has been set.

### n Speed indicator display conditions and vehicle speed setting range

Vehicle speed setting range: Approximately 30 to 100 mph (approximately 50 to 160 km/h)

When the maximum speed is selected, the speed indicator comes on only in red.

# $\,{\rm n\,}$ Tacho indicator display conditions and engine speed setting range

Engine rpm setting range: Approximately 2000 to 6500 rpm (r/min) When the maximum rpm is selected, the tacho indicator comes on only in red.

# **⚠** NOTICE

#### n To prevent damage to the engine and its components

- 1 Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- 1 The engine may be overheating if the temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 400)

#### 2-2. Instrument cluster

# Indicators and warning lights

The indicator and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

► Instrument cluster



The units used on the speedometer and the tachometer gauge display may differ depending on the model/type.

► Center panel



#### n Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator  $(\rightarrow P. 128)$ 



an automatic transmission)

"ECT SNOW" indicator  $(\rightarrow P. 123)$ 



Headlight high beam indicator  $(\rightarrow P.143)$ 



"ETCS SNOW" indicator (→P. 126)



Headlight indicator  $(\rightarrow P. 143)$ 



a manual transmission)

"ECT PWR" indicator (→P.123)



Tail light indicator  $(\rightarrow P. 143)$ 



an automatic transmission)

Cruise control indicator  $(\rightarrow P. 152)$ 



Front fog light indicator  $(\rightarrow P. 146)$ 



"AFS OFF" indicator light  $(\rightarrow P.144)$ 



(vehicles with an automatic transmission)

Shift position and shift range indicators ( $\rightarrow$ P. 122)



Intuitive parking assist indicator ( $\rightarrow$ P. 164)



Slip indicator ( $\rightarrow$ P. 171)



"VSC OFF" indicator  $(\rightarrow P. 172)$ 



SRS airbag on-off indicator ( $\rightarrow$ P. 90)

# n Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems.  $(\rightarrow P. 360)$ 



\*: These lights turn on when the "ENGINE START STOP" switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Lexus dealer.

# **A** CAUTION

### ${f n}$ If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Lexus dealer immediately if this occurs.

2

# Multi-information display

The multi-information display presents the driver with a variety of drivingrelated data, including the current outside air temperature.



- 1 Trip information  $(\rightarrow P. 140)$ 
  - Displays driving range, fuel consumption and other cruising related information.
- 1 Satellite switch mode display  $(\rightarrow P. 245)$

This switch is used to configure various function settings.

- 1 Intuitive parking assist display (if equipped)
  - Automatically displayed when using intuitive parking assist.
- Dynamic radar cruise control display (if equipped)
   (→P. 155)

Automatically displayed when using dynamic radar cruise control.

1 Warning messages

 $(\rightarrow P.369)$ 

Automatically displayed when a malfunction occurs in one of the vehicle's systems.

### Trip information

▶ Without navigation system



Display items can be switched by pushing the "DISP" switch.

▶ With navigation system



### n Outside temperature

0UTSIDE **75**°F Displays the outside air temperature.

The temperature range that can be displayed is from  $-40^{\circ}F$  ( $40^{\circ}C$ ) to  $122^{\circ}F$  ( $50^{\circ}C$ ).

When the temperature drops to  $37^{\circ}F$  ( $3^{\circ}C$ ), the digits of the display will flash for 10 seconds.

### n Driving range



Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

### n Average fuel consumption



Displays the average fuel consumption since the function was reset.


The function can be reset by pushing the "DISP" switch for longer than one second when the average fuel consumption is displayed.

# n Average fuel consumption after refueling



Displays the average fuel consumption since the vehicle was last refueled.

### n Current fuel consumption



Displays the current rate of fuel consumption.

### n Average vehicle speed



Displays the average vehicle speed since the engine was started or the function was reset.

The function can be reset by pushing the "DISP" switch for longer than one second when the average vehicle speed is displayed.

# n Gear position display (vehicles with an automatic transmission only)



Indicates the current gear, and the range of gears that is available when the shift lever is in the S or D position, the gear range is shown by the number of dots (•) and the current gear is shown as a number. The transmission automatically selects the gears within the driver selected gear range.

In the illustration to the left, a range of 6 available gears (1 through 6) has been selected by the driver. (The shift lever is in the D or S position with 6 ranges enabled) It is possible for the transmission to automatically select between all 6 of the gears. In this case, the transmission has selected third gear.

#### n System check display

After switching the "ENGINE START STOP" switch to IGNITION ON mode, "CHECK" is displayed while system operation is checked. When the system check is complete, "COMPLETED" is displayed before returning to the normal screen.

### **A** CAUTION

### n The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in personal death or injury.