Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

| ltem | Function | Default setting | Customized setting |
|---|--|---|--------------------------------------|
| Smart access system with push-button start (→P. 33) | Operation signal (Emergency flashers) | On | Off |
| | Operation signal (Buzzer) | On | Off |
| Wireless remote control (→P. 45) | Unlocking operation | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| | Automatic door lock function to be activated if door is not opened after being unlocked | On | Off |

| ltem | Function | Default setting | Customized setting |
|----------------------------------|--|-----------------|--------------------|
| Wireless remote control (→P. 45) | Time elapsed before automatic door lock function is activated if door is not | 60 seconds | 30 seconds |
| | opened after being unlocked | | 120 seconds |
| | Operation signal (Emergency flashers) | On | Off |
| | Operation signal (Buzzer) | On | Off |
| (/ 11 10) | Door lock buzzer | On | Off |
| | Trunk unlocking function | On | Off |
| | Trunk unlocking operation | Push and hold | Push twice |
| | | | One short push |
| | Panic function | On | Off |

| ltem | Function | Default setting | Customized setting |
|-------------------------|--|---|--------------------------------------|
| | Unlocking using a key | Driver's door unlocked in one step, all doors unlocked in two steps | All doors unlocked in one step |
| | Speed-detecting auto- matic door lock function (Manual transmissions) | On | Off |
| Door lock | Speed-detecting auto- matic door lock function (Automatic transmissions) | Off | On |
| (→P. 48) | Opening driver's door unlocks all doors (Manual transmissions) | On | Off |
| | Opening driver's door unlocks all doors (Auto- matic transmissions) | Off | On |
| | Shifting gears to P unlocks all doors | On | Off |
| | Shifting gears to a position other than P locks all doors | On | Off |
| Steering wheel (→P. 73) | Auto tilt-away function | On | Off |

| ltem | Function | Default setting | Customized setting |
|--|---|-----------------|-----------------------|
| Power windows (→P. 80) | Linked door key operation | Open and close | Off |
| | | | Open only |
| | | | Close only |
| | Wireless remote control linked operation | Off | Open only |
| | Linked door key opera- tion | Open and close | Off |
| Moon roof (→P. 83) | | | Open only |
| | | | Close only |
| | Linked operation of com- ponents when door key is used | Slide only | Tilt only |
| | Wireless remote control linked operation | Off | Open only |
| | Linked operation of com- ponents when wireless remote control is used | Slide only | Tilt only |
| Automatic light control system (→P. 172) | Light sensor sensitivity | Level 3 | Level 1 to 5 |
| | Time elapsed before headlights automatically turn off after doors are closed | 30 seconds | 0 seconds |
| | | | 60 seconds |
| | | | 90 seconds |
| Lights (→P. 174) | Daytime running light system (U.S.A. only) | On | Off |

| ltem | Function | Default setting | Customized setting |
|--|--|--|--------------------|
| Windshield wipers and washer (→P.178) | Switching operation when the vehicle is stationary | On | Off |
| | Drip prevention function | On | Off |
| | Time elapsed before the drip prevention function operates | Variable depending on the vehicle speed | 3 seconds |
| Intuitive park- | Back sensor operation display and buzzer | On | Off |
| ing assist | Buzzer volume | Level 3 | Level 1 to 5 |
| (→P.190) | Distance which a sensor detects | 4.9 ft. (150 cm) | 2.0 ft. (60 cm) |
| | Time elapsed before lights | 15 seconds | 7.5 seconds |
| | turn off | | 30 seconds |
| | Operation when the doors are unlocked | On | Off |
| Illumination (→P. 325) | Operation after the "ENGINE START STOP" switch is turned OFF | On | Off |
| | Front footwell lights | On | Off |
| | Shift lever light | On | Off |
| | Outer foot light | On | Off |
| Seat belt reminder (→P. 473) | Vehicle speed linked seat belt reminder buzzer | On | Off |

Multi-information display (\rightarrow P. 167)

| Country | Available languages |
|---------|---------------------|
| Canada | English and French |