Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

ltem	Function	Default setting	Customized setting
Smart access system with	Operation signal (Emergency flashers)	On	Off
push-button start (→P. 28)	Operation signal (Buzzer)	On	Off
Wireless remote con- trol (→P. 40)	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off

ltem	Function	Default setting	Customized setting
Wireless remote con- trol (→P. 40)	Time elapsed before auto- matic door lock function is activated if door is not	60 seconds	30 seconds
	opened after being unlocked		120 seconds
	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
()1.10)	Door lock buzzer	On	Off
	Trunk unlocking function	On	Off
	Trunk unlocking operation	Push and hold	Push twice
			One short push
	Panic function	On	Off

6-2. Customization

ltem	Function	Default setting	Customized setting
Door lock (→P. 43)	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Speed-detecting auto- matic door lock function (Manual transmissions)	On	Off
	Speed-detecting auto- matic door lock function (Automatic transmissions)	Off	On
	Opening driver's door unlocks all doors (Manual transmissions)	On	Off
	Opening driver's door unlocks all doors (Auto- matic transmissions)	Off	On
	Shifting gears to P unlocks all doors	On	Off
	Shifting gears to a posi- tion other than P locks all doors	On	Off
Steering wheel (→P.70)	Auto tilt-away function	On	Off

ltem	Function	Default setting	Customized setting
Power win- dows (→P. 76)	Linked door key opera- tion	Open and close	Off
			Open only
			Close only
	Wireless remote control linked operation	Off	Open only
	Linked door key opera- tion	Open and close	Off
			Open only
			Close only
Moon roof (→P. 79)	Linked operation of com- ponents when door key is used	Slide only	Tilt only
	Wireless remote control linked operation	Off	Open only
	Linked operation of com- ponents when wireless remote control is used	Slide only	Tilt only
Automatic	Light sensor sensitivity	Level 3	Level1to 5
light control system (→P. 165)	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds
			60 seconds
			90 seconds
Lights (→P. 166)	Daytime running light sys- tem (U.S.A. only)	On	Off

6-2. Customization

ltem	Function	Default setting	Customized setting
Windshield wipers and washer (→P. 169)	Switching operation when the vehicle is stationary	On	Off
	Drip prevention function	On	Off
	Time elapsed before the drip prevention function operates	Variable depending on the vehicle speed	3 seconds
Intuitive park-	Back sensor operation display and buzzer	On	Off
ing assist	Buzzer volume	Level 3	Level1to 5
(→P.190)	Distance which a sensor detects	4.9 ft. (150 cm)	2.0 ft. (60 cm)
	Time elapsed before lights	15 seconds	7.5 seconds
	turn off		30 seconds
Illumination (→P. 329)	Operation when the doors are unlocked	On	Off
	Operation after the "ENGINE START STOP" switch is turned OFF	On	Off
	Front footwell lights	On	Off
	Shift lever light	On	Off
	Outer foot light	On	Off
Seat belt reminder (→P. 473)	Vehicle speed linked seat belt reminder buzzer	On	Off

Multi-information display (\rightarrow P. 160)

Country	Available languages
Canada	English and French