1 Before driving

1-1. Key information 2

Keys 2

1-2. Opening, closing and locking the doors and trunk 4

Smart access system with push-button start 4

Wireless remote control 14

Doors 17

Trunk 21

1-3. Adjustable components 25

Front seats 25

Driving position memory system 27

Head restraints 30

Seat belts 33

Steering wheel 39

Inside rear view mirror 40

Outside rear view mirrors 41

1-4. Opening and closing the windows and moon roof 43

Power windows 43

Moon roof 46

1-5. Refueling 49

Opening the fuel tank cap 49

1-6. Anti-theft system 52

Engine immobilizer system 52

Alarm 54

Theft prevention labels (U.S.A.) 56

1-7. Safety information 57

Correct driving posture 57

SRS airbags 59

Front passenger occupant classification system 70

Child restraint systems 76

Installing child restraints 79

2 When driving

2-1. Driving procedures 90

Driving the vehicle 90

Starting the engine 97

Transmission 100

Turn signal lever 104

Parking brake 105

2-2. Instrument cluster 106

Gauges and meters 106

Indicators and warning lights 110

Multi-information display 113

2-3. Operating the lights and windshield wipers 116

Headlight switch 116

Fog light switch 119
Windshield wipers and washer..... 120
Headlight cleaner switch 123

2-4. Using other driving systems.... 124

Cruise control 124
Dynamic radar cruise control... 127
Intuitive parking assist 136
Rear view monitor system 155
AVS (Adaptive Variable Suspension System) (GS430) 158
Driving assist systems..... 159
PCS (Pre-Collision System)..... 165

2-5. Driving information 168

Cargo and luggage..... 168
Vehicle load limits..... 171
Winter driving tips 172
Trailer towing..... 177
Dinghy towing 178

3 Interior features

3-1. Using the touch screen 180

Touch screen 180
Setting the touch screen 184

3-2. Using the air conditioning system and defogger..... 190

Automatic air conditioning system 190
Rear window and outside rear view mirror defoggers 198

3-3. Using the audio system..... 199

Audio system type 199
Using the radio..... 202
Using the cassette player 211
Using the CD player..... 215
Playing MP3 and WMA discs 223
Using the DVD player 231
Playing DVD video/audio..... 234
Playing video CD..... 247
DVD player and DVD video disc information 251
Optimal use of the audio/video system..... 255
Using the steering switches..... 259

3-4. Using the hands-free system 262

Hands-free system 262
Using the Bluetooth® phone 267
Setting the hands-free system 280

3-5. Using the interior lights..... 306

Interior lights list..... 306

3-6. Using the storage features..... 310

List of storage features..... 310

3-7. Other interior features..... 316

Sun visors..... 316
Vanity mirror..... 317
Clock..... 318
Outside temperature display... 319
Ashtrays..... 320
Cigarette lighter..... 321
Power outlet..... 322
Seat heaters..... 323
Seat heaters and ventilators.... 325
Armrest..... 327
Rear sunshade..... 328
Floor mats..... 330
Trunk features..... 331
Garage door opener..... 334
Compass..... 339
Lexus Link System..... 343

4 Maintenance and care

4-1. Maintenance and care..... 358

Cleaning and protecting the vehicle exterior..... 358
Cleaning and protecting the vehicle interior..... 360

4-2. Maintenance..... 363

Maintenance requirements..... 363
General maintenance..... 365
Emission inspection and maintenance (I/M) programs..... 368

4-3. Do-it-yourself maintenance.. 369

Do-it-yourself service precautions..... 369
Hood..... 372
Positioning the jack..... 373
Engine compartment..... 375
Tires..... 390
Tire inflation pressure..... 400
Wheels..... 404
Air conditioning filter..... 406
Electronic key battery..... 409
Checking and replacing fuses..... 411
Headlight aim..... 429
Light bulbs..... 431

5 When trouble arises

5-1. Essential information..... 438

If your vehicle needs to be towed..... 438
If you think something is wrong..... 445
Fuel pump shut off system..... 446
Event data recorder..... 447

5-2. Steps to take in an emergency..... 449

If a warning light turns on or a warning buzzer sounds ... 449
If a warning message is displayed ... 455
If you have a flat tire (Vehicles with run-flat tires) ... 472
If you have a flat tire (Vehicles with standard tires) ... 473
If the engine will not start ... 483
If the shift lever cannot be shifted from P ... 484
If you lose your keys ... 485
If the electronic key does not operate properly ... 486
If the vehicle battery is discharged ... 488
If your vehicle overheats ... 492
If the vehicle becomes stuck ... 495

6 Vehicle specifications

6-1. Specifications ... 498
Maintenance data ... 498
Fuel information ... 508
Tire information ... 511

6-2. Customization ... 523
Customizable features ... 523

6-3. Initialization ... 527
Items to initialize ... 527

7 For US owners

Reporting safety defects for U.S. owners ... 530

Index

Alphabetical index ... 532

What to do if ... 540